

AlphaFreshbox 200 WiFi With and without Radon sensor Manual

March 2021





RadonTec GmbH

Hauptstraße 5 89426 Wittislingen - Germany Tel: (+49) 9076 - 919 98 35 E-Mail: info@radontec.de Website: radontec.de Shop: radonshop.com

Version: 01



Scope of Contents

1	Introduction4				
2	Safety instructions4				
	2.1 Safety precautions during unit installation5				
	2.2	Safety instructions for operating the unit	7		
3	Int	ended use	10		
4	Sco	ope of delivery	11		
5	Те	chnical data	12		
6	Dir	nensions	13		
7	De	esign and operating logic	14		
8	As	sembly and operation	17		
	8.1	Mounting	18		
	8.2	Mains connection	25		
	8.3	Connecting additional control units	26		
	8.4	Control	28		
	Re	mote control	30		
9	Em	nergency stop	51		
10	10 Error codes/warnings52				
11	11 Troubleshooting5				
12	12 Maintenance and servicing54				
13	13 Transport and storage5				
14	14 Disposal5				
15	5	Two year warranty	58		
16	16 Support and Contact6				



1 Troubleshooting/FAQ	62
2 Contact Us	62

1 Introduction

The AlphaFreshbox 100 WiFi is a ventilation unit with enthalpy exchanger and WiFi connection. It is designed for controlled air exchange in detached houses, offices, hotels, cafés, conference rooms and other residential and commercial spaces. It is used for heat recovery from the extract air to heat the supply air.

2 Safety instructions



Read the operating instructions carefully before using and installing the single room heat recovery unit.

Read the operating instructions carefully and keep them for as long as you use the AlphaFreshbox 100 WiFi.

When handing over the unit control, the operating instructions must be handed over to the operator taking over the unit.



The installation and operation of the unit must be carried out in accordance with this user manual and with the provisions of all applicable local and national



building, electrical and technical regulations and standards.



The warnings contained in this user manual must be taken particularly seriously as they contain important information regarding personal safety.



Failure to follow the safety instructions may result in injury or equipment damage.

2.1 Safety precautions during unit installation



Before any installation or repair procedure, the unit must be disconnected from the power supply.



The unit must be earthed!



Do not operate the unit outside the temperature range specified in the user manual or in aggressive or explosive environments.



Do not use damaged equipment or wiring to connect the unit to the mains.





Observe the specific safety regulations for the use of power tools when installing the appliance.

Unpack the appliance with care.

Unauthorised modifications to the mains cable are not permitted. Do not bend the mains cable. Do not damage the mains cable. Do not place any objects on the mains cable.



Do not place any heaters or other devices in the immediate vicinity of the mains cable of the unit.



All assembly and maintenance work may only be carried out by electricians with a valid electrical work permit for electrical work on the units up to 1000 V after carefully studying these operating instructions.

Make sure that the impeller and the housing are not damaged before connecting the unit to the mains. The casing installations must be free of foreign bodies that could damage the impeller blades.



Take measures to prevent contact with the fan to avoid physical damage during unit testing and commissioning.

Misuse of the product or unauthorised modification is not permitted.

Take measures to prevent smoke, carbon monoxide and other combustion products from entering the room through open chimney flues or other fire protection devices. There must be sufficient air supply for proper combustion and exhaust of gases through the chimney of fuel burning appliances to prevent backflow. The maximum permissible pressure difference per dwelling unit is 4 Pa.

The conveyed air must not be aggressive to steel at the temperature specified in the table in the "Technical data" section.

2.2 Safety instructions for operating the unit



Do not touch the controller or remote control with wet hands. Do not perform maintenance on the unit with wet hands.



Do not wash the unit with water. Protect the electrical parts of the unit from water penetration.





Use the appliance only as intended by the manufacturer. Do not connect tumble dryers or similar appliances to the appliance or to the ventilation system!

Do not place any containers with water, e.g. vases, on the unit.



Do not sit on the unit and do not place any objects on the unit.



All work on the electrical connections of the unit, maintenance and repair work is only permitted when the unit is deenergised.



Do not allow children to operate the unit.



Do not damage the mains cable while the unit is in operation. Do not place any objects on the mains cable.





Keep explosive and flammable products away from the unit.

Do not open the control panel.

In case of unusual noises, disconnect the unit from the power supply and contact the Service Centre.



If the unit is in continuous operation, check the mounting safety regularly.

Do not close or block the intake or exhaust air openings of the unit so as not to disturb the normal air flow.

Make sure that the air flow of the unit is not directed towards appliances with an open flame or candles.



The unit is not intended to be used by children, physically or mentally handicapped persons, persons with sensory disorders or persons without appropriate qualifications.





Installation and connection work may only be carried out by suitably qualified personnel after receiving appropriate safety instruction.



The installation site of the appliance must be secured against access by unsupervised children..

3 Intended use

The unit is not suitable for the ventilation of swimming pools, saunas, greenhouses, summer gardens and other humid rooms.

Thanks to heat recovery and its energy-saving properties, the unit is one of the crucial elements for energy-efficient, modern house construction. The unit is a component of a ventilation system and is not designed for stand-alone operation. The unit is designed for continuous operation with a permanent power supply.

The conveyed medium must not contain explosive and flammable substances, chemical vapours, sticky substances, fibrous materials, dust, soot, oil particles and other harmful substances such as poisons, pathogens.

The ventilation system can be used in closed rooms at temperatures from +1 $^{\circ}$ C to +40 $^{\circ}$ C and a relative humidity of max. 70 %.

The dew point temperature of the conveyed air must be 2-3 °C below the temperature of the enclosure surface so that no condensate can form inside the enclosure.



The unit belongs to class I electrical installations. Protection class against ingress of foreign bodies and water:

- IP22 for the mounted ventilation unit,

- IP44 for the motor units.

4 Scope of delivery

Please check the completeness of the scope of delivery using the following parts list:

1x ventilation system

1x operating manual

1x Mounting template

1x Fastening set

1x Magnetic sheet

1x Key

1x spigot



5 Technical data

Max. Delivery rate	30 m³/h	60 m³/h	90 m³/h	120 m³/h	200 m³/h
Supply voltage, V/50 (60)	1~ 230 Hz				
Max. Power consumption excluding	10 W	15 W	25 W	44 W	134 W
Sound pressure level at a distance of 3 m	12 dBA	22 dBA	30 dBA	36 dBA	45 dBA
Max. Power consumption of the ventilation system			4,0 A		
Conveying medium temperature	-15 to +40 °C				
Material of the casing	Painted steel				
Insulation	30 mm				
Efficiency of heat recovery	75 %	70 %	68 %	67 %	66 %
Type of heat exchanger		Countercu	rrent heat e	exchanger	
Heat exchanger material	Enthalpy membrane				



Supply air filter	G4 + F7 (H13 optional)	
Exhaust air filter	G4	
Diameter of the connection spigot	Ø 100 mm	
Weight	44 kg	

6 Dimensions







7 Design and operating logic



The warm, used exhaust air enters the ventilation system from the room, is cleaned in the exhaust air filter and flows through the heat exchanger. It is then led outdoors by the exhaust air fan via the exhaust air pipe.

The fresh outside air flows into the ventilation system and is cleaned in the supply air filter. The air then continues to flow through the heat

exchanger and is led into the room by the supply air fan.

In the heat exchanger, the heat from the warm extract air is transferred to the cold outside air. Here, the two air flows are completely separated from each other.



The heat recovery minimises heat loss in the cold season and thus saves heating costs.

The unit is equipped with a recirculation damper. In recirculation mode, it is open and the supply and extract air dampers are closed.



The stale exhaust air flows through the filters, is cleaned again, and is then fed further into the room through a heat exchanger.

Depending on the model, the ventilation system is equipped with a pre-heating or post-heating coil. This provides automatic protection against overheating of the heating coil.

AlphaFreshbox 200 WiFi is equipped with a pre-heating coil. If the supply air temperature is below -3 °C, the pre-heating coil automatically heats the supply air so that the average temperature of the extract air downstream of the heat exchanger is not below +5 °C. The extract air fan runs on the heating coil.

The extract air fan runs at the maximum ventilation level. No condensate forms in the ventilation system with enthalpy heat exchanger because the humidity of the extract air is transferred to the supply air via the enthalpy membrane. The shutters open automatically when the fan motors are switched on and close when they are switched off.





It is possible to connect an additional exhaust air spigot (Ø 100 mm) for the removal of air from other rooms, for example the bathroom. The

connection piece is included in the scope of delivery.

The exhaust air grille must be closed with the magnetic plug included in the scope of delivery (see "Installation and preparation for operation").



8 Assembly and operation



Read these operating instructions carefully before installing the unit!



Sufficient maintenance access must be considered when mounting the unit.

The recommended minimum distances between the ventilation unit and the walls are as follows:





8.1 Mounting



Before mounting, make sure that the fan housing does not contain any foreign parts such as foil or paper.



The unit must be mounted on a smooth surface. Mounting the unit on an uneven surface will cause distortion of the housing and malfunction of the unit.

1. A drilling template for marking the holes is included.

Tape the template to the wall at the required height.

Use the template to mark the holes for the ventilation pipes, the attachment of the unit and the outlet of the power cable. Lay all cables and pipes to the installation site before starting the installation work.



2. Remove the template and drill two core holes for the ventilation pipes with a diameter of 120 mm.



When installing the ventilation system with a two-room connection, prepare a hole for the connection bend and the laying of the ventilation pipe in the wall. The connection bend and the ventilation pipes are available as accessories.

Drill the holes with a diameter of 8 mm and a depth of 90 mm. Insert the dowels. Remove the perforated fields for the ventilation pipes from the template and reattach the template with the adhesive tape.



3. Cut the ventilation pipes to the required length: On the outside wall, the ventilation pipe must protrude by the length required for mounting the outside ventilation bonnet (A). For details, see the installation instructions for the ventilation bonnet.

The external bonnet is not included in the scope of delivery of the ventilation system and is available as an optional accessory.





4. Fix the template to the wall.

Insert the ventilation pipes into the wall via the template openings.



Fix the ventilation pipes inclined downwards by 3 mm with wedges to allow the condensate to drain off.

To install the ventilation system with a second room connection, place the connection elbow in the hole prepared for it in the wall and fix it with wedges. Connect the connection elbow to the air duct.



5. Fill the cavities between the air ducts and the wall over the entire length through the openings made for this purpose in the template with installation foam.



After the foam has cured, remove the template and remove the excess foam.

Cut off the protruding parts of the pipes so that they are flush with the inner wall.

6. Inserting an additional exhaust vent: remove the plug at the back of the unit. To do this, unscrew the screws, remove the plug and fix the spigot in its place with the screws.



Manual – AlphaFreshbox 200 WiFi



7. Open the unit and remove the heat exchanger.

Loosen the fixing screws and remove the protective cover to access the fixing holes.



8. Remove the F7 and H13 filters to gain access to the mounting holes.



9. If an exhaust air spigot is fitted, remove the protective cover and fit the magnetic plug to the exhaust air grille.





Disconnect the earth cable when removing the cover.

10. He Lift the unit and insert the drain connection piece and the connection pieces into the corresponding ventilation pipes.

When laying the ventilation pipes, observe a minimum slope of 3 mm.

Fasten the system with the screws supplied (included in the scope of delivery). The system is fixed with four screws.

Reinsert the filters, the earthing cable and the protective covers into the ventilation system and close the access door of the system.





11.Insert the outer bonnet:

Remove the excess foam.

Fill the cavities between the ventilation pipe and the wall with a sealant.

Fix the outer bonnet to the outer wall of the building (see assembly instructions for the outer bonnet).





8.2 Mains connection



The unit must be disconnected from the mains before any work is carried out!



Electrical connections may only be carried out by an authorised specialist!



The basic electrical data of the unit are given on the manufacturer's label.

The unit is intended for connection to a single-phase AC mains supply of ~110-240 V/50(60) Hz in accordance with the connection diagram.

The unit is to be connected to the power supply via insulated, electrical power lines (cables). When selecting the appropriate line circuit breaker, attention must be paid to the maximum load current and the maximum wire temperature, which depends on the conductor type, insulation, length and routing type.

A circuit breaker built into the stationary power supply network must be installed at the external input to interrupt the circuit in the event of a short circuit or overload. The installation location of the line circuit breaker must be quickly accessible in the event of an emergency shutdown of the ventilation system. The rated tripping current of the miniature circuit breaker must match the current consumption of the ventilation system, see technical data. To select the tripping current, take the next value of the miniature circuit breaker in the series after the maximum current consumption of the unit.



The miniature circuit breaker is not included in the scope of delivery and can be ordered separately.

8.3 Connecting additional control units



To access the control unit, open the unit door, remove the protective panel, undo the screws securing the side wall, and remove it.

Connection of the automatic fire fighting system contact (PK)

Remove the jumpers between the terminals 5 and 6. In case of fire, the normally closed dry contact breaks the control circuit from the central fire-fighting board and cuts off power supply to the unit.



Connection of the contact for activating the Boost mode

The unit provides for the connection (parallel to the humidity sensor installed at the factory) of a normally open contact for activating the Boost mode. When the contact closes, the unit switches to maximum speed.



* The unit is not included in the delivery set.



8.4 Control

The ventilation system is controlled via the control panel on the housing of the ventilation system, via the remote control and via the app.





The ventilation system is switched on/off by pressing the On/Off button 0.

The ventilation modes of the system are controlled with the \blacksquare and \blacktriangleright buttons.

The \blacksquare and \blacktriangleright buttons change the ventilation mode in five steps.

Pressing \blacksquare and \blacktriangleright simultaneously for more than 3 seconds switches the timer on/off. The timer time and the ventilation level at which the system is switched during timer operation are set via the app.

Switching the reheating coil on/off is done with the button

The timed operation is switched on/off with the key 🗉 .

For this operating mode, the time must be set correctly in the app.

By default, the control unit saves a time-controlled operation with the factory settings.

The switch-on button of the time-controlled operation blocks the buttons for switching the ventilation levels and for switching the reheating on/off.

Switching the WLAN module on/off is done with the key 🔊.

This key result is used to switch the WLAN module on/off. If the key is pressed for longer than 5 seconds, it starts flashing and the control unit switches to "Setup Mode".

At the end of the filter life, the filter change indicator **I** on the control panel lights up to indicate that the filters need to be replaced.





After the ventilation system is switched off, the fans continue to run to cool down the heating coil. The switch-off time of the fans is 0.5-2 minutes, depending on the model of the ventilation system.

Remote control



Control via app on mobile device For Android in the Google Play Store: https://play.google.com/store/apps/details?id=com.embarca dero.BlaubergFRESHBOX





For IOs in the Apple Store: <u>https://apps.apple.com/us/app/blauberg-</u> <u>freshbox/id1402506523</u>



WiFi technical data

Standard	IEFE 802,11, /g/n
Frequency band, GHz	2,4
Transmission power, mW (dBm)	100(+20)
Network	DHCP
WLAN security	WPA, WPA2

If the app is started without connecting to the system, the following message is displayed on the screen of the mobile device:





By default, the fan functions as a WLAN access point. After installing the app, connect the mobile device to the fan as a Wi-Fi access point with the name (FAN: + 16 characters of the ID number) as indicated on the control board and the housing of the unit.

The default password of the WLAN access point: 11111111 (eight one).

Call up the installed app on the mobile device that is connected to the fan.

- Select the desired connection type.
- Call up the menu of the app 😑.



- Select the menu item Connection - Home.

If the mobile device is connected to WLAN access point without router, then select the default connection. In case of



connection via router, search for ventilation equipment in the network Q.

- Select the connection with the required ID.

- Edit the connection by pressing the button \oslash .

- If necessary, change the connection name, enter the password of the system (valid characters: 0 ... 9, a...z, A...Z). The default password of the system is 1111 (four ones).

- Confirm the entered data by pressing the key 🗹.





Changing the password of the system

- Go to the menu (😑) Connection Home.
- Select the connection and press the key 🚳.
- Enter and confirm the password. Valid characters: 0...9, a...z, A...Z
- Press the Change Password key.

← MENU		Connection / At home	← Connection / At home
 Home page 	>	Default (i)	
Basic settings	~	New ID-0020001E41345716	New password
Connection	^		Confirm password
At home	>		Chappe password
P Through cloud server	>		Change password
🗢 Wi-Fi setup	>		Control through the cloud server
Engineering menu	~		
Alarms	>		
(i) About app	>		
	\odot	\oplus \otimes \oslash \bigcirc \bigcirc	



WLAN settings

Go to the application menu on your mobile device menu () - Connection - Wi-Fi settings.



Press Receive. The current settings of the WLAN parameters are displayed on the screen. Select one of the WLAN modes Access point or Client.

Access point: Access point without a home router.

In this mode, up to 8 mobile devices can be connected to the fan to control it.

Select the desired security level for the Access point mode:

Open: not password protected. WPA PSK: password protected. WPA2 PSK: password protected. WPA/WPA2 PSK: password protected (recommended).



Enter the password of the WLAN access point. Change the WLAN channel if necessary.

Press the Apply button.

≡ Wi-Fi setup
Wi-Fi modes
Access point Client
Security modes
WPA/WPA2 PSK +
Wi-Fi password
8 - 64 characters
Wi-Fi channel
Receive Apply

Client: the fan runs in the network of the home router. Enter the data of the home router for the client mode and the type of IP address:

- Enter the name of the home router's WLAN access point.

- Enter the password of the WLAN access point of the home router.

Select the type of IP address:

DHCP: automatic assignment of the IP address when connecting to the home router (recommended). Static: allows the IP address, subnet mask and default gateway to be assigned manually.

These settings are only recommended for experienced users.



It is not recommended to select this type of IP address yourself. Press the Apply button.

≡ Wi-Fi setup
Wi-Fi modes
Wi-Fi name
1 - 32 characters
Wi-Fi password
0 - 64 characters
Type of IP address
DHCP +
Receive Apply

Special Setting Mode "Setup Mode

If you lose the Wi-Fi password or password of the unit, connect external devices and for other reasons, the special setup mode is used to edit the settings.

To switch to the special setup mode, press and hold the Wi-Fi button on the control panel of the ventilation unit for 5 seconds until the LED flashes.

The unit is in this mode for 3 minutes, after which it automatically returns to the previous settings. To exit the setting mode immediately, press and hold the button again for 5 seconds until the LED stops flashing. The following parameters are available for connecting to the system in setup mode:

WLAN name: Setup Mode.



WLAN password: 111111.

The password of the system is ignored.

Connection via Cloud Server

It is possible to control the unit via cloud servers using the app. With this function, you can control the system connected to the home router from any distance with an Internet connection. By default, control via Cloud Server is switched off. Activation is as follows:

- Call up the menu item Connection Home.
- Select the required connection type.
- Call up the connection settings menu.
- Activate the control via cloud server.



Warning. If this function is activated, WLAN connection faults of the home router can lead to temporary communication failures with the ventilation units.



← MENU		
Home page	>	Default (j)
Basic settings	~	New 10: 0020001E41345716 New password
Connection	^	Confirm password
At home	>	Change password
Through cloud server	>	Change password
奈 Wi-Fi setup	>	Control through the cloud server
🛞 Engineering menu	~	
Alarms	>	
(i) About app	>	
	\bigcirc	\oplus \otimes \emptyset $\textcircled{0}$ \otimes

To control the system, create a new account or log in to a previously created one. In the programme menu of the mobile device, open Menu - Connection - Via Cloud Server:

- Press the Add New Account button.

- Enter your login, password and e-mail address to re-enter the password. Confirm the entered data by pressing the key

- Follow the link that was sent via e-mail.
- Enter your login data and password and log in.
- Add a new connection by pressing the button $\textcircled{m m \Theta}.$
- Enter the name of the ventilation unit and ID. The ID number of the ventilation unit is indicated on the control board.
- The default password is 1111.



- Confirm the entered data by pressing the key \checkmark .
- Press the key 📲 if necessary to log out.





Menu structure





<u>Startseite</u>



Type of current connection to the ventilation system. House connection or connection via cloud server



Filter change indicator



Rotes Leuchten – Alarmanzeige, oranges Leuchten – Warnanzeige



Red light - alarm indicator, orange light - warning indicator Heat dissipation indicator of the electric heating coil before the system is switched off

Boost Boost operation indicator



The current temperature of the sensor that controls the air temperature.





Control buttons



Switching the ventilation system on/standby

Selection of the ventilation level

Activation of the timer. The timer settings are made in the menu Basic settings - Timer.

Activation of timer-controlled operation. The settings for this mode are made in the menu Basic settings - Timer menu

Recirculation: Activation of the recirculation mode. If there is no recirculation mode, the key is inactive.

Heating register: Selection of the temperature setpoint for the post-heating register or switching off the heating register.



Basic settings

<u>Timer</u>

Main Timer: Settings for Timer Mode

When the timer is activated in the Home menu, the system goes to the following settings:



- **00:30** Setting the timer time
- Selection of the control temperature +15 ° C..
 + 30 ° C, off are available. If OFF is selected, temperature control is not executed during timed operation.

<u>Boost follow-up time:</u> determines the follow-up time for boost mode after the signal at the digital input (boost switch) on the control board disappears.

<u>Boost switch-on delay:</u> determines the switch-off delay time for boost mode after the signal at the digital input (boost switch) has been applied.





<u>Schedule</u>

The schedule can be set with 4 time periods per weekday. Setting can be done for each day or immediately for the whole week, weekdays,

weekends. After activating the schedule in the Home menu, the ventilation system runs according to the schedule according to the following parameters:



Ventilation level selection 1-5 Standby

- 06:00 09:00 Time setting for a specific period of time
- Selection of the control temperature +15 ° C..
 + 30 ° C, off are available. If OFF is selected, temperature control is not executed during timed operation.





Date and time

In this menu, the current time and date are displayed and their settings are also made.

Time display format: HH:MM:SS

Date format: DD.MM.YYYY



Manual entry of date and time

The same time as on the mobile device is set automatically.





<u>Filter</u>

≡	Filter	
Time le	eft to filter main	tenance
Days:	Hours:	Minutes:
0	21	58
R	eset the filter tin	ner
F	ilter timer setpo	int
-		90 days
т	otal operation ti	me
Days:	Hours:	Minutes:
89	2	2

Filter timer setting: After the set time (70-365 days), the filter change indicator appears and the corresponding filter change information is displayed in the alarm menu.

Total operating time: shows the running time of the unit, which cannot be reset.

<u>Other</u>



The backlight changes dynamically, after releasing the button the brightness decreases to a preset value.

Sound - switches the loudspeaker on the board on/off.



Engineering menu

Air flow rate



Air flow rate, preset ventilation level 1-5 and boost are set in this section.



Sensors

This section shows the current status of all sensors:



Outdoor air temperature

Supply air temperature

Exhaust air temperature in front of the heat exchanger

Exhaust air temperature behind the heat exchanger

Firmware



This menu shows the current version and date of the control unit and control panel firmware.



Factory settings



In this menu you can reset all settings to the factory settings. After resetting, the connection with the device may be lost. If necessary, set up the WLAN connection again.

<u>Alarms</u>



Alarms and warnings are displayed in this menu. Alarms are marked in red, warnings are marked in black. Alarm indicates a serious error in operation. The ventilation system is forcibly switched off.

The alarm is reset manually with the Reset alarms button. Warning - the system is not forcibly switched off.

Warnings are automatically reset after the cause has been eliminated.



9 Emergency stop

In emergency situations, the system is switched off and the
display▲flashesthealarmcode:•- short light signal-- long light signal

Alarm code	Alarm description
	Outdoor temperature sensor missing
•	Short circuit on outdoor air temperature sensor
•	Sensor behind the heating coil missing
••	Short-circuit on sensor after the post-heating coil
•	Exhaust air temperature sensor before the heat exchanger is missing
• _ •	Short circuit on extract air sensor
••	Exhaust air temperature sensor after the heat exchanger is missing
••••	Short circuit on the sensor after the heat exchanger in the extract air duct
-•	Reserved
_••	Reserved
••_	Sensor behind the heat exchanger in the supply air duct is missing
•••	Short circuit on the sensor after the heat exchanger in the supply air duct.
_••	Empty battery. The time-controlled operation will not work correctly.
•••	Reserved
	Fire alarm activation
	Remote control connection error with the control unit (not shown in the app).
•	Wifi module initialisation error
• • • •	Unknown error (contact your dealer if this error occurs).



10 Error codes/warnings

Fehler	Beschreibung
0	Alarm! Fehlfunktion des Zuluftventilators
1	Alarm! Fehlfunktion des Abluftventilators
2	Alarm! Der Außenlufttemperatursensor wurde nicht gefunden.
3	Alarm! Kurzschluss des Außenlufttemperatursensors
4	Alarm! Der Zulufttemperatursensor wurde nicht gefunden.
5	Alarm! Kurzschluss des Zulufttemperatursensors
6	Alarm! Der Ablufttemperatursensor vor dem Wärmetauscher wurde nicht gefunden.
7	Alarm! Kurzschluss des Ablufttemperatursensors vor dem Wärmetauscher
8	Alarm! Der Ablufttemperatursensor nach dem Wärmetauscher wurde nicht gefunden.
9	Alarm! Kurzschluss des Ablufttemperatursensors nach dem Wärmetauscher
10	Alarm! Betätigung des Schutzthermostats des Vorheizregisters
11	Alarm! Betätigung des Schutzthermostats des Hauptheizregisters
23	Warnung! Der Akku ist leer. Der zeitgesteuerte Betrieb wird nicht korrekt funktionieren.
25	Alarm! Feueralarm-Aktivierung
40	Warnung! Der Filterwechsel-Timer ist abgelaufen. Wechseln Sie den Filter.
50	Alarm! Keine Verbindung zum Bedienfeld und zur Steuereinheit
51	Alarm! Kein zusätzlicher Zulufttemperatursensor vor dem Hauptheizregister
52	Alarm! Kurzschluss des zusätzlichen Zulufttemperatursensors vor dem Hauptheizregister



11 Troubleshooting

Malfunction	Possible reasons	Remedy
The fan(s) do not start when the system is switched on.	No power supply	Check whether the power supply is connected correctly. If not, rectify the connection error.
Cold supply air	Dirty exhaust air filter	Clean or replace the exhaust air filter.
	Icing of the heat exchanger	Check the heat exchanger for icing. If necessary, switch off the ventilation system and allow the ice to melt.
	Failure of the heating coil	Contact your dealer.
Low flow rate	Dirty filters, fans and heat exchangers	Clean or replace the filters, clean the fans and the heat exchanger.
	Clogged or damaged ventilation system	Check for unobstructed opening of diffusers and louver shutters, check the exhaust hood and the supply grille and clean those, if necessary. Make sure the air ducts are clean and intact.
Loud noise, vibrations	Dirty fan impellers	Clean the impellers.
	The screw connection is loose.	Tighten the fastening screws.



12 Maintenance and servicing



Disconnect the unit from the power supply before performing maintenance on the unit.

Maintenance work is recommended 3-4 times a year. Maintenance of the ventilation unit includes regular cleaning of the unit surfaces from dust and filter replacement or cleaning.

Maintenance of the ventilation system includes regular cleaning of the unit surfaces and filter replacement or cleaning.

1. Filter maintenance (3-4 times per year)



Dirty filters increase air resistance and reduce the supply air volume flow.

Remove the dirty filters from the unit:

Clean F7 filters with a hoover.

To remove the G4 filters for cleaning, remove the flexible fixing clips. Rinse the filters with water and let them dry.



After drying, reassemble the filters in the reverse order. Put the filters back into the ventilation unit.

Clean the filters as needed, but at least 3-4 times a year. Contact the dealer for replacement filters.

2. Maintenance of the heat exchanger (1 time per year)



Even if the filters are cleaned regularly, some dust may accumulate in the heat exchanger.

> Therefore, the heat exchanger must also be cleaned regularly for continued high efficiency.

Regular dry cleaning is recommended. A hoover with a narrow suction nozzle is best

suited for this.

Pull the heat exchanger out of the ventilation system, clean it with a hoover and put it back into the ventilation system.



3. Fan maintenance (1 time per year)



Even with regular filter maintenance, some dust may build up on the fans, reducing fan performance and supply air flow.

Clean the fans with a soft cloth or brush.

Cleaning with water, abrasives, sharp objects, etc. is not permitted in order not

to damage the impeller.

4. Maintenance of the supply air grille (2 times per year)

Leaves and other dirt can clog the supply air grille and reduce the delivery rate. Check the condition of the supply air grille regularly and clean it of foreign objects as necessary.

5. Maintenance of the ventilation pipes (every five years)

Even if you carry out all the recommended maintenance regularly, some dust may get into the ventilation pipes and thus reduce the delivery rate and volume flow.

Maintenance consists of regular cleaning or replacement of the ventilation pipes.



13 Transport and storage

Store the unit in its original packaging in a ventilated room at a temperature of +5 $^{\circ}$ C to +40 $^{\circ}$ C and a relative humidity up to a maximum of 70 %.

Vapours and foreign substances in the air that may cause corrosion and damage connection seals are not permitted.

During handling operations, use lifting equipment to prevent possible damage.

The transport requirements for this type of cargo must be met.

Transport with vehicles of any kind must be carried out under constant protection against damaging mechanical and weather-related influences. Transport the unit only in the operating position.

Carry out loading and unloading operations carefully, protect against shocks.

Before first use after transport at low temperatures, the unit must be kept at room temperature for at least 3-4 hours.



14 Disposal



WARNING

Do not dispose of the appliance in household waste.

The appliance contains materials that can be recycled and materials that must not be disposed of with household waste.

At the end of its service life, dispose of the unit in accordance with the regulations in force at your location.

15 Two year warranty

We guarantee this appliance for a period of two years from the date of sale. If a material or manufacturing defect occurs within the 2-year warranty, the appliance will be repaired or replaced at our expense, provided that the consumer complies with the regulations for transport, storage, assembly and operation.

The product complies with the European norms and standards, the directives on low voltage and electromagnetic compatibility. We hereby declare that the product complies with the relevant requirements of Directive 2014/30/EU on electromagnetic compatibility, Low Voltage Directive 2014/35/EU and Directive 93/68/EEC on CE marking.



In the event of malfunctions of the appliance due to defects caused at the factory that occur within the warranty period, the consumer is entitled to have the defects in the appliance remedied free of charge by means of warranty repair by the manufacturer.

The warranty repair includes in particular work to remedy defects in the operation of the appliance in order to ensure that the appliance can be used as intended within the warranty period.

The rectification of defects is carried out by replacing or repairing the defective parts or units of the unit.

The warranty does not cover parts of the unit that are subject to normal wear and tear (e.g. filters) and can therefore be regarded as wearing parts.

The warranty does not apply in the following cases:

- The consumer does not present the fan in its entirety as specified in the operating instructions, including the components of the unit disassembled by the consumer.

- Non-compliance of the model or brand of the unit with the information on the packaging and in the operating instructions.

- Failure by the consumer to carry out timely technical maintenance of the appliance.

- In the event of external damage to the housing and internal units caused by the consumer (except for external modifications to the unit that are necessary for assembly).



- Changes to the construction of the unit or technical modifications to the unit.

- Replacement and use of units or parts not intended by the manufacturer.

- Inappropriate use of the unit.

- Violation of the installation instructions of the appliance by the consumer.

- Violation of the regulations for the control of the appliance by the consumer.

- Connection of the appliance to a mains supply with a voltage other than that specified in the operating instructions.

- Failure of the appliance due to voltage jumps in the mains.

- Independent repair of the appliance by unauthorised persons.

- Repairs to the unit by persons who are not authorised by the manufacturer.

- Expiry of the warranty period of the unit.

- Violation of applicable regulations concerning the transport of the appliance by the consumer.

- Violation of regulations concerning the storage of the appliance by the consumer.

- Illegal actions by third parties in relation to the appliance.

- Failure of the appliance due to force majeure (fire, flood, earthquake, war, military action of any kind, blockades).



- Absence of seals if provided for in the operating instructions.

- Failure to present the operating instructions with the date of purchase indicated.

- Absence of the proof of purchase with the date of purchase shown, which confirms the purchase.

The warranty service requires that sufficient proof, e.g. a proper invoice, is presented and that the warranty claim is made within the warranty period.

For the warranty repair, the consumer must present the appliance, the operating instructions with the note of the date of purchase and a payment receipt as confirmation of the purchase.

The model of the appliance presented must correspond to the model indicated in the operating instructions. Contact the seller of the unit for warranty service.

In the event of a warranty claim, we recommend that you contact us first. To obtain this warranty service, please contact us at: info@radontec.de



16 Support and Contact

16.1 Troubleshooting/FAQ

You will find answers to the most frequently asked questions on our website:

https://www.radontec.de

16.2 Contact Us

Should you have any further questions or require further help and technical support, please do not hesitate to contact us.

RadonTec GmbH

Hauptstraße 5 89426 Wittislingen - Germany Tel: (+49) 9076 - 919 98 35 E-Mail: info@radontec.de Website: radontec.de Shop: radonshop.com